

GPO Retro – GPO PR100 Setup Guide

Thanks for purchasing the GPO PR100. To correctly set up your unit and begin enjoying high quality sound, please consult the following steps.

1. Unpack your GPO PR100 and remove the platter from its cardboard box.
2. Ensure that the elastic band around the interior rim of the platter is not twisted and that it is flush with the platter's base.



3. Unpack the base unit and place it on a flat, stable surface
4. Holding the platter with the flat side down, place a finger through one of the larger holes and stretch the elastic band around this finger (see image below left).
5. Holding the platter with the flat side up, place a finger through the same hole and stretch the elastic band around this finger. This will help you attach it to the drive shaft. Hold the band securely with your finger and thumb (see image below right).



6. Gently lower the platter onto the central spindle of the base unit, ensuring that the elastic band is stretched over the drive shaft.

7. Gently release the elastic band and remove your finger from the hole. The band should now be securely attached to the drive shaft.



8. Remove the ties securing the tone arm.
9. Attach the counterweight to the tone arm. This counterweight can be tightened or loosened to adjust the pressure on the stylus.
10. Plug the supplied AC adaptor into the base unit and into a wall socket.
11. Use the provided RCA cable to connect the base unit to the amplifiers.
12. Place a vinyl record onto the turntable and adjust the counterweight so that the stylus applies the correct amount of pressure.
13. Turn the unit on using the Power On/Standby button.
14. Select PHONO and the correct record speed.
15. Turn the Start/Stop selector to Start.
16. Release the tone arm holder, lift using the lever and move it to your preferred location on the vinyl.
17. Gently lower the tone arm to begin playback.
18. If the turntable does not spin, ensure that the elastic band is correctly attached to the drive shaft as shown in the image above.

Further help

If you are still experiencing problems, contact our customer service team on:

0330 024 0383.